

**Instructions for re-stringing the Variation series by David Roy of Wood That Works:**

1. Unwind both the front and back arm strings from the back spool. Make sure they are hanging straight down.
2. Hook the front (furthest from the wall) string to the front arm.
3. Wrap the back string around the spool 3 times clockwise and hook it to the back arm.